May-24 BMWST





#### **Specifications:**

- Safe Working Capacity: 34kg
- Adjustable Working Height: 960-1500mm
- Castor Wheel Diameter: 75mm
- Tabletop Dimensions: 797L x 695W (mm)
- Main Tray Dimensions: 556L x 695W (mm)
- Distance between front castors: 955mm
- Depth at full width: 485mm



#### About the Borum brand

Our "heavy duty commercial" range of Borum Industrial equipment has been manufactured to exacting standards for the past 34 years. We specify industrial quality components and design to ensure a long and durable working life in commercial transport, mining, earthmoving and railway environments. Our Borum Industrial range of equipment is focused on achieving superior professional standards, reliability, quality, and are covered by a 12 month trade use warranty.

Made in China to TQB Brands Pty Ltd specifications Visit us at www.tqbbrands.com.au May-24 **BMWST** 

## WARNING INFORMATION













## IMPORTANT: READ ALL INSTRUCTIONS BEFORE USE



#### WARNING

The instructions and warnings contained in this manual should be read and understood before using or operating this equipment. Do not allow anyone to use or operate this equipment until they have read this manual and have developed a thorough understanding of how this equipment works. Failure to observe any of the instructions contained in the manual could result in severe personal injury to the user or bystanders, or cause damage to the equipment and property. Keep this manual in a convenient and safe place for future reference.

The warnings, cautions and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.

Whilst every effort has been made to ensure accuracy of information contained in this manual, the Borum policy of continuous improvement determines the right to make modifications without prior warning.

## **CONTENTS**

| WARNING INFORMATION                           | 1 |
|---|---|
| STANDARD OPERATING PROCEDURE                  | 2 |
| ASSEMBLY, OPERATION, PREVENTITIVE MAINTENANCE |   |
| PARTS LIST & DIAGRAM                          |   |
| AMADDANITY                                    |   |

May-24 BMWST

## STANDARD OPERATING PROCEDURE

**DO NOT** sit or stand on this mobile workshop table.



Safety glasses must be worn when operating this equipment



Safety footwear must be worn when operating this equipment



Long loose hair must be contained when operating this equipment



Close fitting/protective clothing must be worn when operating this equipment

## **PRE-OPERATIONAL SAFETY CHECKS**

- 1. DO NOT exceed this rated capacity.
- 2. Study, understand, and follow all instructions before operating this device.
- 3. Retain these instructions for future reference.
- 4. The equipment described in this manual could be potentially dangerous if improperly or carelessly operated. For the protection of all persons and equipment, only competently trained operators who are critically aware of the proper operating procedures, potential dangers, and specific application of this equipment should be allowed to use this equipment at any time.
- 5. Because of potential hazards associated with this type of equipment, no alterations shall be made to this product.
- 6. Failure to heed all warnings contained in this manual may result in personal injury and/or property damage.
- 7. All warranties applicable to this equipment are contingent on strict adherence to the operation and maintenance procedures in this manual.

#### **OPERATIONAL SAFETY CHECKS**

- 1. DO NOT exceed the safe working capacity of 34kg.
- 2. DO NOT sit or stand on the mobile workshop table.
- 3. DO NOT adjust the table height when loaded. Remove all items before performing any height adjustments.
- 4. Center the load, tipping of the mobile workshop table can cause injury and damage.
- 5. Only use this mobile workshop table on a smooth, level, surface. Keep the surface free from unrelated materials and ensure that there is adequate lighting.
- 6. When servicing, use only Borum identical replacement parts. Use of any other parts will void the warranty.
- 7. Use the right product for the job. Do not modify the mobile workshop table.

May-24 **BMWST** 

## **ASSEMBLY, PREVENTITIVE MAINTENANCE**

## 1. FEATURES

The Heavy Duty steel construction makes this BORUM "Industrial Quality" Truck Mobile Workshop Table durable enough for moving tools and car parts to and from the vehicle. The extra wide and deep legs make using them with larger trucks a breeze. Easily handles loads up to 34kg. Solid castors ensure you can manoeuvre this mobile workshop table around the workshop floor. The height adjustment gives you plenty of options for your commercial vehicle needs. This very versatile mobile work top makes any installation or service work flow more efficiently for auto repairers and installation workshops.

## Assembly

- Attach the castor wheels (1) to the left and right legs (20 and 21)
- Attach the legs (20 and 21) to the lower cross beam (19)
- Mount the lower table support (4) to the lower cross beam (19)
- Attach the table (10) to the upper table support (8)

#### 3. OPERATION



#### Warning:

Vehicles must be properly and adequately supported before commencing work, do not use this mobile workshop table as a wheel chock.

Prior to each use conduct a visual inspection checking for abnormal conditions, such as cracked welds, leaks, and damaged, loose, or missing parts.

#### 4. STORAGE

This mobile workshop table should always be stored in a dry location on a level surface with the table in the lowered position.

#### **MAINTENANCE**


Replace or repair damaged parts. Use genuine Borum replacement parts only. Non authorised parts may be dangerous and will invalidate the warranty.

## 6. SERVICE & REPAIR

Any piece of equipment found damaged in any way or found to be worn or operates abnormally should be removed from service until repaired by an authorised service agent. Owners and / or operators should be aware that repair of this product may require specialised equipment and knowledge. Only authorised parts, labels, decals shall be used on this equipment.

# **PARTS LIST & DIAGRAM**

| Part | Description                 | Qty |
|------|-----------------------------|-----|
| 1    | Castor wheel 3"             | 4   |
| 2    | Fork nut M10*25             | 4   |
| 3    | Plastic plug 40*25          | 4   |
| 4    | Outer (lower) table support | 1   |
| 5    | Washer M8                   | 16  |
| 6    | Lock washer                 | 16  |
| 7    | Bolt M8*16                  | 16  |
| 8    | Inner (upper) table support | 1   |
| 9    | Height adjustment screw     | 1   |
| 10   | Table                       | 1   |
| 11   | Plastic stopper             | 4   |
| 12   | Recessed head screw M5*8    | 1   |
| 13   | Foam pad casing             | 1   |
| 14   | Main tray foam pad          | 1   |
| 15   | Parts tray foam pad         | 1   |
| 16   | Corner protector            | 8   |
| 17   | Plastic pin                 | 16  |
| 18   | Tool tray foam pad          | 1   |
| 19   | Lower cross beam            | 1   |
| 20   | Left leg                    | 1   |
| 21   | Right leg                   | 1   |



May-24 BMWST

## **WARRANTY**

BORUM Industrial products have been carefully tested and inspected before shipment and are guaranteed to be free from defective materials and workmanship for a period of 12 months from the date of purchase except where tools are hired out when the guarantee period is ninety days from the date of purchase.

Should this piece of equipment develop any fault, please return the complete tool to your nearest authorised warranty repair agent, or contact TQB Brands Pty Ltd Warranty team - warranty@tqbbrands.com.au.

If upon inspection it is found that the fault occurring is due to defective materials or workmanship, repairs will be carried out free of charge. This guarantee does not apply to normal wear and tear, nor does it cover any damage caused by misuse, careless or unsafe handling, alterations, accident, or repairs attempted or made by any personnel other than the authorised TQB Brands Pty Ltd repair agent.

This guarantee applies in lieu of any other guarantee expressed or implied and variations of its terms are not authorised.

Your TQB Brands Pty Ltd guarantee is not effective unless you can produce upon request a dated receipt or invoice to verify your proof of purchase within the 12-month period.

#### **Consumer Guarantee**

Our goods come with a guarantee that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.



All images and illustrations shown are for reference purposes only. All information, specifications and illustrations in this manual are based on the latest information available at the time of publication and are subject to change without notice. The information in this manual is periodically revised to ensure the latest information is included. Download the latest version of this manual and other related technical documentation from <a href="https://www.tgbbrands.com.au">www.tgbbrands.com.au</a>